

# ProBase installation guide for log cabins



Lay out your ProBase on a firm and level sub base  
Fill with 10mm round pea gravel



Build up your log walls



Lay out the bearer kit  
and attach the first log beam



Complete your building



NEED FRIENDLY ADVICE?  
0800 195 6968